




## Jog Operation

Location	How to setup
Tool Icons or Properties	Click 

Enable to move the pin free within marking area by using the arrow keys.

It is also useful to setup XY coordinate visually and setup starting position with Rotary Device.



--- Instructions ---

1. Make the fields on the preview in advance.
2. Choose a pitch from the pull-down menu.
3. Setup the XY coordinate by using the arrow keys. Pin also moves at same timing.
4. Choose the field want to setup from the pull-down menu and click **Setup** button.
5. Click **Confirm** button
6. For setup multi fields, repeat steps 3 and 4.